TLILIC3018

Licence to Drive a Multi Combination Vehicle

Learner Guide Instructions

Who is this document for?

The learner.

What is in this document?

- Course information that matches the PowerPoint presentation.
- Review questions.

What do you need to do before you use it for the first time?

- 1. Rebrand the document.
- 2. Review the document as part of your validation process.

See the 'Read Me First' document for a complete set of instructions on how to use these resources.



TLILIC3018 Licence to Drive a Multi-Combination Vehicle

Learner Name:		
Learner ID:		
Learner Contact Number:		
Learner Contact Number.		
Learner Email Address:		
Date Training Commenced:		
This Book Conta	nins:	
☐ Course Inform	mation.	
☐ Review Ques	tions	
Likeview Ques	tions.	

Table of Contents

1.1 Introduction	5
1.1.1 What is a Multi-Combination Vehicle?	
1.1.1.1 Vehicle Transmissions	
1.1.1.2 Types of Transmissions	
1.2 Road Rules and Legislation	
1.2.1 Licence Requirements	
1.2.2 Road Rules	
1.2.3 Permits	
1.2.4 Work Health and Safety Legislation	10
1.2.5 Fatigue Management	
1.2.6 Environmental Protection	
Review Questions.	
2.1 Carry Out Pre-Operational Checks	
2.1.1 Conduct Visual Inspection	
2.1.2 Check Wheels and Tyres	
2.1.3 Check Fluid Levels	
Review Questions	
2.2 Carry Out Operational Checks	
2.2 Carry Out Operational Checks	16
2.2.1 Entering the Vehicle	
2.2.2 Operational Checks 2.2.2.1 Engine	
2.2.2.2 Exhaust System	
2.2.2.3 Instruments and Gauges	17
2.2.2.4 Brakes	
2.2.2.5 Controls	
2.2.2.6 Qualified Mechanic's Checks	
2.3 Check Signage and Lights	20
2.3.1 Signage	20
2.3.2 Lights, Indicators and Reflectors	۷۱
2.4 Couple and Uncouple Primer Mover, Trailer and Dolly	22
2.4.1 Coupling a Semi-Trailer	
2.4.2 Uncoupling a Semi-Trailer Review Questions	
2.5 Check Loads and Restraints	
2.5.1 General Principles of Load Restraint	
2.5.1.1 Carry a Load Safely	
2.5.1.3 Load Restraint	
Review Questions	
2 (Apply for Dormite	20
2.6 Apply for Permits	
Review Questions	
3.1 Drive and Position the Multi-Combination Vehicle	
3.1.1 Vehicle Handling Procedures	
3.1.2.1 Choosing Appropriate Speeds	
Traffic and Speed	
Driving Around Bends	33
3.1.2.2 Being Observant	
Use Your Mirrors	
שוווע อหูบเง	

Special Mirror Checks	35
Negotiating Complex Traffic Situations	
3.1.2.3 Keeping a Safe Distance	
Managing Space Around Your Vehicle	
Handling Tailgaters	
3.1.2.4 Accelerating and Steering	
3.1.2.5 Braking	
Operation of Air Brakes	
3.1.2.6 Turning Two Turning Lanes	
Tips for Turning a Long Vehicle	
3.1.2.7 Changing Gears	
3.1.2.8 Driving Up and Down Hills	
3.1.2.9 Obeying Road Signs	
3.1.2.10 Reversing the Vehicle	
Review Questions.	
3.2 Monitor Vehicle Performance and Efficiency	45
3.2.1 Check Engine Power	45
Excessive Smoke	
3.2.2 Check Vehicle Controls and Instruments	46
Review Questions	46
3.3 Monitor Traffic and Road Conditions	47
3.3.1 Driver Responses	4 J
Review Questions	48
3.4 Identify and Respond to Driving Hazards	49
3.4.1 Hazard Controls	49
3.4.1.1 Defensive Driving Techniques	50
3.4.1.2 General Hazard Avoidance or Control	51
3.4.1.3 Fatigue Management	51
Causes of Fatigue	51
Fatigue Warning Signs	52
Fatigue Management Techniques	
3.4.1.4 Stress Management	
Stress Management Techniques	
Review Questions	54
3.5 Follow Driving Emergency Procedures	55
3.5.1 Emergency Procedures	
3.5.1.1 Emergency Braking	56
3.5.1.2 Evasive Steering	57
3.5.1.3 Horn Use	
3.5.1.4 Skidding	
3.5.1.5 Brake Failure	
3.5.1.6 Tyre Failure	58
3.5.1.7 Vehicle Breakdown or Loss of Load	58
3.5.1.8 Crashes	
3.5.1.9 Fire	
Engine Fire	
Review Questions	59
3.6 Interacting with Other Road Users	40
3.6.1 Communications Equipment	
3.6.2 Common Driving Communications	
3.6.3 Emergency Communications	
Review Questions	01
4.1 Park, Shut Down and Secure Multi-Combination	on Vehicle63
Review Questions	
4.2 Complete Documentation	
4.2.1 Work Diary	
Review Questions	66
Appendix A - Multi-Combination Vehicle Inspection	on Checklist 67
Teps. Tail. 1. That it combination vehicle inspection	

1.1 Introduction

These materials are based on the unit of competency TLILIC3018 Licence to Drive a Multi-Combination Vehicle.

They cover the information and skills required to obtain a licence to drive a multi-combination vehicle including:




- Systematic and efficient control of all vehicle functions.
- Monitoring of traffic and road conditions.
- Management of vehicle condition and performance.
- Coupling and uncoupling of trailers and dollies (smaller trailers that attach to trailers).
- Effective management of hazardous situations

This unit of competency is designed for those wanting to become a driver of multi-combination vehicles that may be driven:

- On public roads.
- On private roads.
- Within worksites.

The assessment for this course will be:

- Undertaken within a licensing examination.
- Conducted by, or under the authority of, the relevant Heavy Vehicle Driver Licensing Authority.



1.1.1 What is a Multi-Combination Vehicle?

A multi-combination (MC) vehicle is any heavy combination vehicle with more than one trailer or dolly. It may be driven by the holder of a Multi-Combination Vehicle Driver Licence.



Trailers may include:

- ◆ A semi-trailer an unpowered vehicle which is attached to a prime mover by a turntable, forward of the prime mover's rear axle, for the purpose of being towed by that vehicle.
- ◆ A dolly, i.e. a small trailer that can be coupled to a truck or trailer so as to support a semi-trailer. The dolly is attached to a fifth wheel to which the semi-trailer is coupled.

Multi-combination vehicles are also known as road trains or B-doubles.

1.1.1.1 Vehicle Transmissions

An important factor in driving and operating any multi-combination vehicle is the relationship between the engine and its transmission.

A motor vehicle engine consists of:

- A power source, and
- A power transmission system, i.e. a system to control the application of power.

A conventional transmission is an assembly of parts which include:

- Gears or gear ratios which are used to change vehicle speed and direction.
- ◆ A propeller shaft or driveshaft by which the power is transmitted from an engine to a live axle.
- A final drive shaft to one or more differentials which in turn drive the wheels





The purpose of a transmission is to:

- Adapt the power output of the engine to the drive wheels.
- Reduce the higher engine speed to the slower wheel speed, increasing torque in the process.

1.1.1.2 Types of Transmissions

Professional drivers of multi-combination vehicles need to recognise different types of transmissions.

There are three types which provide the ability to switch between gears as speed changes. They are:

- ♦ A manual transmission, i.e. the driver manually changes gears.
- An automatic transmission, i.e. the gear box automatically changes gears; suited to smaller vehicles that have to frequently stop and start.
- ◆ A semi-automatic or automated manual transmission, i.e. manual gear box with automated gear change; the driver can change gears without the need for a clutch.





Manual transmission is the most commonly used as it is efficient and able to withstand the stress of hauling heavy loads.

Manual transmissions can have two types of gear box:

- ♦ Non-synchromesh (crash or constant mesh gear box) the matching of the engine and driving speed depends on your judgement and skill as there are no synchronisers in the gear box to help you. Double declutching is essential while you are learning to use the gear box.
- ♦ Synchromesh works in much the same manner as in most modern cars, i.e. the synchronising of the gears is done by the gear box. These transmissions can be damaged if gear changes are forced before the engine and road speeds are matched.

In summary, recognising the type of transmission in the multi-combination vehicle you will be driving means that you can operate the vehicle efficiently, effectively and safely.

Review Questions

1.	What are the 3 types of transmission that may be found in multi-combination vehicles?	
1.		
2.		
3.		

1.2 Road Rules and Legislation

There are special rules and regulations that apply to multi-combination vehicles and obligations that apply to you as a multi-combination vehicle driver.

These include relevant state/territory regulations and legislation such as:

- Roads and traffic authority driving regulations and licence requirements pertaining to multi-combination vehicles.
- Road rules, instructions, procedures, information and signs.
- Permit regulations and requirements.
- Work Health & Safety (WHS) legislation.
- Fatigue management regulations.
- Environmental protection legislation.





1.2.1 Licence Requirements

A multi-combination vehicle may be driven by the holder of Multi-Combination Vehicle Driver Licence.

In states and territories the highest level of heavy vehicle licence is a multi-combination licence which allows you to drive all types of vehicles except motorcycles. The licence class is Road Train or B-double (MC) Multi-Combination.

You are eligible for a multi-combination licence if you have held a Heavy Rigid or Heavy Combination licence or equivalent for one year or more.



You must also successfully complete an approved multi-combination training course.

It is a legal offence to drive, or allow someone else to drive, a vehicle without the relevant licence.

You must display "Driver Under Instruction" plates at the front and rear of the vehicle while you are learning to drive a multi-combination vehicle and you must be supervised by someone who has a multi-combination licence.

While learning to drive any type of heavy vehicle, you must have a zero Blood Alcohol Concentration (BAC) at all times.

Be aware that holding a vehicle licence does not automatically entitle you to drive passenger vehicles. To drive passenger vehicles such as buses you need to have:

- A Driver Certificate.
- A good driving record.
- No criminal convictions, including sex, alcohol or drug offences.
- No medical condition that may impair your driving skills.



1.2.1.1 Medical Eligibility

There is a wide range of medical, hearing and eyesight conditions which will prevent the issue of a multi-combination vehicle licence.

Some common conditions that may affect the issue of a licence include:



- Visual defects, including loss of vision in one eye.
- Hearing defects.
- Angina, heart disease/surgery/hypertension, having a pacemaker.
- Some psychiatric disorders.
- Epilepsy.
- Diabetes.
- Sleep apnoea.
- Head injuries, dementia, stroke.
- Parkinson's disease, multiple sclerosis.
- Physical disabilities/partial or complete loss of limbs.

Having these conditions does not necessarily prevent the issue of a licence but careful evaluation will be needed. In some cases a restricted licence may be considered.

If you are concerned that you may not be eligible, you should speak to your doctor or contact the relevant authority in your state or territory before you undertake driver training or testing.

If you have a medical condition, it is in your own interest to ensure that it is appropriate for you to apply for the category of vehicle in which you are interested.

All drivers are legally obliged to notify their relevant state or territory authority if they have or develop a medical condition that may impact on their ability to drive safely.

In addition to the appropriate licence, you may also be required to obtain a Driver Certificate to drive a vehicle carrying passengers for hire and reward. Strict eyesight requirements apply to Driver Certificate applicants.



1.2.2 Road Rules

Drivers must comply with all road rules including these four main areas:

- Signage on roadways (all categories), structures, other vehicles.
- Speed limits.
- Seat belt laws for driver and passengers.
- Alcohol and drugs laws.





It is against the law to drive under the influence of alcohol or drugs (including some over-the-counter and prescription drugs). Never use stimulants to stay awake while driving.

Police have the power to conduct roadside alcohol and drug tests.

All drivers and passengers should wear a secure and properly adjusted seatbelt.

Road rules are enforced by police and transport safety services. You must stop when signalled and comply with their directions.

They may check:

- Your licence or work diary.
- The mass, height and width of your vehicle.
- The mass, height and width of your load.
- The condition of your vehicle.

1.2.3 Permits

Some vehicles such as passenger buses or special purpose vehicles may require a special permit in order to be operated.

Carrying dangerous goods or oversized loads may also require a permit.

Vehicle operators will need to carry their permits with them at all times while conducting permit work.



1.2.4 Work Health and Safety Legislation

Work Health & Safety (WHS) laws and guidelines help keep your workplace safe.


These can be broken down into four main types:

Acts	Laws to protect the health, safety and welfare of people at work.
Regulations	Gives more details or information on particular parts of the Act.
Codes of Practice	Are practical instructions on how to meet the terms of the Law.
Australian Standards	Give you the minimum levels of performance or quality for a hazard, work process or product.

It is important that you are familiar with the WHS laws that exist in your state or territory. Each state in Australia has its own WHS legislation and regulations that must be followed. Your state or territory may refer to Work Health and Safety (WHS) as Occupational Health and Safety (OHS).

The following WHS legislative requirements will affect the way that you work:

- Australian Standards.
- Industry WHS Standards and Guidelines.
- Duty of Care.
- Health and Safety Representatives, Committees and Supervisors.
- WHS and Welfare Acts and regulations.
- Job Safety Analysis (JSA) and Safe Work Method Statements (SWMS).
- Licences, Tickets or Certificates of Competency.
- National safety standards.
- Safety Codes of Practice.



This means complying with safe work practices, including activities that require licences, tickets or certificates of competency or any other relevant state and territory WHS requirements.





State/territory legislation sets out maximum work times and minimum driving and rest times for operators of multi-combination vehicles.

1.2.6 Environmental Protection

It is important that multi-combination vehicle operations do not have a negative impact on the environment.

Impacts may include:

- Noise pollution.
- Exhaust fumes and smoke.
- Vehicle leaks.
- Material falling from vehicles (e.g. chemical spills).

It is important to keep vehicles in good working order and to safely secure loads to avoid these issues.







Review Questions

2.	List 3 relevant state or territory regulations that apply to the operation of a multi-combination vehicle.	
1.		
2.		
3.		
3.	What are the 4 main road rules you must obey when driving a multi-combination vehicle?	
3.	What are the 4 main road rules you must obey when driving a multi-combination vehicle?	
	What are the 4 main road rules you must obey when driving a multi-combination vehicle?	
1.	What are the 4 main road rules you must obey when driving a multi-combination vehicle?	

2.1 Carry Out Pre-Operational Checks

As a driver you are legally responsible for the safety and roadworthiness of the vehicles you drive. It is your responsibility to maintain the performance of your multi-combination vehicle through regular daily and weekly inspections and checks.



The time you spend in checking your vehicle is an investment in safety, efficiency and trouble-free operation. It also reduces maintenance costs and the need to pay fines.

Routine checks conducted before driving any vehicle ensure it is safe and roadworthy and you are well prepared for your journey. A checklist such as the one shown in Appendix A may be used when conducting these checks.

Pre-operational (or pre-start) checks are essential and are carried out before starting the engine of the vehicle.

2.1.1 Conduct Visual Inspection

Walk around the vehicle making a visual inspection to check that:

- The vehicle is roadworthy.
- The vehicle does not tilt to the side as this could indicate a flat tyre or overloading.
- The chassis and frame is not damaged.
- There is no rust or corrosion.
- There are no fluid leaks.
- Suspension components are aligned and undamaged.
- All belts and pulleys are undamaged.
- Lines and brake hoses are not damaged or leaking.
- Couplings are undamaged.
- Door latches and hinges are secure and working.
- The body/cab is in a good condition and has not been damaged.
- Windscreen and windows are clean and undamaged.
- Seats are structurally sound.
- Seatbelts are present and in working order.
- Steering wheel is secure and undamaged.
- Mud flaps and guards are fitted.







2.1.2 Check Wheels and Tyres

Check that all wheels are secure, wheel rims are not bent or cracked and that there is the correct number and type of nuts and studs.

Use a gauge to check that all tyres have the correct air pressures. Thumping and kicking the tyres will not help you find out if a tyre has low pressure.

Low pressure causes heat to build up in the tyre and can make steering difficult and unsafe. It can cause dual tyres to rub together and start a fire or cause a blowout.



2.1.3 Check Fluid Levels

Check and, if necessary, top up fluid levels during pre-operational inspections including:



- Engine oil.
- Hydraulic oil.
- Engine coolant.
- Brake fluid.
- Power steering fluid.
- Screen washer fluid.

2.1.4 Other Checks

Other checks you will need to make during a pre-operational inspection include:

- Checking monitors are fitted properly, are in good working order and are calibrated correctly.
- All electrical wiring and connections are undamaged and securely fitted.
- The fuel tank and lines are secure and free from leaks. The fuel tank cap should be properly fitted.
- The gear box is fitted properly.
- Checking coupling equipment and devices such as:
 - Turntable.
 - Kingpin.
 - Skid plate.
 - Locking block.
 - Safety catch.
 - Trailer apron plate.
 - Air lines and electrical cables.
 - Landing gear (trailer supports).
- All safety and emergency equipment is present including:
 - First-aid kit.
 - Fire extinguisher.
 - Warning triangle signs (at least three).
 - Spare fuses.







Review Questions

1.	What are 5 things you need to check during your pre-operational check of the vehicle?	
1.		
2.		
3.		
4.		
5.		
2.	List 3 fluid checks you would make during a pre-operational inspection.	
1.		
2.		
3.		

2.2 Carry Out Operational Checks

Operational checks (or post-start checks) are done after the multi-combination vehicle has been turned on. It is important to follow the manufacturer's instructions and enter the vehicle safely.



2.2.1 Entering the Vehicle



Before conducting operational (or start-up) checks on a multi-combination vehicle you will need to enter the vehicle safely.


This is achieved by:

- Checking for traffic.
- Using steps and grab handles.
- Maintaining three points of contact at all times.

2.2.2 Operational Checks

Before starting the engine, read the vehicle manufacturer's instructions and follow the appropriate start-up procedures.

After making sure the parking brake is on you will need to check the following:



2.2.2.1 Engine



The engine should be functioning effectively without excessive noise or discharged fumes. Check for signs of damage or any problems.

Let the engine idle until full oil pressure shows on the gauge. Increase the engine revs slightly until the water temperature gauge starts to rise.

2.2.2.2 Exhaust System

The exhaust system should not leak, produce excessive noise or be loose or damaged.



2.2.2.3 Instruments and Gauges

Check all instruments and gauges are working correctly.

The oil pressure gauge should register within a few seconds of starting the engine and then gradually rise to the normal position.

The ammeter or volt meter needle should flutter, then show "charge" or "+" on the dial.

Warning lights for oil, coolant, generator or alternator should go out almost immediately if the engine is running normally.



2.2.2.4 Brakes

Check that all brakes are working effectively, including:

Air brakes.

Hydraulic brakes.

Parking brake.

Engine/exhaust brakes.

Speed retarders.

Anti-lock braking systems (ABS).

A typical inspection of air brakes may consist of the following procedure:

- 1. Apply parking brake and switch off engine.
- 2. Drain air tanks.
- 3. Start engine and idle.
- **4.** Check for low air pressure warning systems.
- **5.** Turn off engine when maximum pressure is reached.
- **6.** Chock wheels and release park brake.
- **7.** Apply foot brake and check the drop in air pressure. Repeat this four more times (the air pressure should not drop below half normal system operating pressure).
- 8. Recharge air system.
- **9.** Re-connect air hoses, apply park break and check for leaks.
- **10.** Start the engine, recharge air system, release and re-apply brakes and check again for leaks.





2.2.2.5 Controls



Make sure all controls are functioning correctly including:

- Steering wheel check for any slackness or looseness.
- Clutch depress until you feel a slight resistance (some free play is normal).
- Accelerator.
- Brake and brake warning lights.
- Interior and dashboard lights.
- Switches and signal lamps.
- Windscreen wipers and washers.
- Audible warning devices, e.g. horn.